

# WIPES FOR LENS CLEANING

Specially Designed for Cleaning  
High Power CO<sub>2</sub> Laser Lenses

Ophir Optics **EZ Clean™** and **EZ Clean™ Plus** are innovative disposable wipes for routine cleaning and deeper cleaning of optical High Power Laser Lenses. Composed of special non-scratch fabric, the liquid dipped wipes deposit a pre-measured amount of quick-drying cleaning fluid that leaves no residue.



Composed of special non-scratch fabric, EZ Clean Wipes deposit a pre-measured amount of ethanol, which is ideal for routine cleaning of laser lenses. A single wipe cleans one lens in a matter of seconds, replacing a five-step procedure using ethanol, cotton swabs and lens paper.



EZ Clean™ Plus, Ophir's most recent innovative wipe, is used for deeper cleaning of optical laser lenses in conjunction with Ethanol based EZ Clean™ Wipes (see above). When deeper cleaning is required, EZ Clean™ Plus wipes are used to counteract the quick-drying effect of the ethanol with a vinegar-based solution that separates dust and other contaminants from the lens surface more effectively. A final once-over with a new Ethanol based wipe removes any residue, and in a matter of seconds the lens is clean and ready for use.



Ophir EZ-Clean™ and EZ Clean™ Plus Packages each include 24 ready-to-use wipes; A few seconds cleaning translates into longer lens life-time and significantly shorter down-time for our customers' lasers.



People and Products You Can Rely On

# LENS CLEANING INSTRUCTIONS

## Routine Lens Cleaning Instructions Using **EZ Clean™** Wipes



**Step 1:**  
Separate one EZ Clean™ wipe



**Step 2:**  
Take out the folded EZ Clean™ wipe



**Step 3:**  
Using an "S" motion, wipe from top to bottom



**Step 4:**  
Turn the lens upside down



**Step 5:**  
Turn the EZ Clean™ wipe to the other side



**Step 6:**  
Using an "S" motion, wipe from top to bottom



**Step 7:**  
Properly dispose the wipe and package

# USING EZ-Clean™ WIPES

## Deeper Cleaning With EZ Clean™ Plus Wipes



**Step 8:**

Take out the folded EZ Clean™ Plus wipe



**Step 9:**

Using an "S" motion, wipe from top to bottom



**Step 10:**

Turn the lens upside down



**Step 11:**

Turn the EZ Clean™ Plus wipe to the other side



**Step 12:**

Using an "S" motion, wipe from top to bottom



**Step 13**

Properly dispose the wipe and package



**Step 14:**

Repeat steps 1-7 with a new EZclean™ wipe,  
in order to remove residues



To maximize effectiveness of cleaning with **EZclean™** wipes we recommend:



- Wearing finger cots or rubber gloves



- Using Ophir lens holder



- Clean working environment

**CONTAINS:**

24 Lens cleaning wipes.

**HEALTH HAZARD INFORMATION**

for health hazard information, please refer to MSDS.



Warning: Cleaning liquid is flammable;  
keep package away from hot surfaces