

2.2.5 Pulsar Multichannel and Triggered USB Interfaces

Convert your laptop or desktop PC into a multichannel power/energy meter

- From sensor to interface to PC
- 1,2 and 4 channel models
- Plug and play with most Ophir sensors
- Record every energy pulse at up to 25kHz
- Measure missing pulses & trigger output with external trigger
- Log power and energy, average, statistics, histograms and more with included StarLab application
- LabVIEW VIs and COM Object Interface included



Smart Sensor to Pulsar to PC

Ophir's 1-4 channel Pulsar interface turns your PC or laptop into a full fledged Ophir multi-channel laser power/energy meter. Just install the software, plug the sensor into the Pulsar and the USB cable from the Pulsar to the PC USB port. With the Pulsar series, you can connect up to 4 sensors to each module, monitor each pulse at up to 25kHz and utilize external trigger.



LabVIEW



Pulsar-4 operating with StarLab software

Specifications


| | |
|----------------------------------|---|
| Power Measurement | |
| Power log period | 5s to 500hr. |
| Energy Measurement | |
| Max real time data logging to PC | 25,000Hz ^(a) |
| Trigger input and output | BNC trigger input to enable measurement of missing pulses or to select specific pulses. Can also be configured to give trigger output |
| Timing | Supports time stamp for each pulse - resolution 1µs |
| General | |
| Number of sensors supported | 4 / 2 / 1 sensors per unit. Can combine several units with software for display of up to 8 sensors on one PC |
| Compatible sensors | Supports all standard Ophir Pyroelectric, Thermal and Photodiode ^(b) sensors |
| Power supply | 12V wall cube power supply plugs into jack on rear. The power supply can be ordered from your local distributor. |
| Dimensions | 103mm L x 190mm W x 33mm H |
| Compliance | CE, China RoHS |
| Notes: | (a) Limited by the maximum repetition rate of the sensor. (b) Not including BC20, PD300-CIE and PD300RM sensors |

Ordering Information

| Item | Description | Ophir P/N |
|---------------------------------|--|-----------|
| Pulsar-4 | Module to operate up to 4 Ophir sensors from your PC USB port. Comes with software. Max repetition rate for every pulse 25kHz. Has external trigger capability. Powered from wall cube power supply (can be ordered from your local distributor) | 7Z01201 |
| Pulsar-2 | Same as above but for 2 channels only | 7Z01202 |
| Pulsar-1 | Same as above but for 1 channel only | 7Z01203 |
| Pulsar USB Cable | USB-A to B cable (1 unit supplied with Pulsar) | 7E01202 |
| N Polarity Power Supply/Charger | Power Supply/Charger AC/DC 12V 2A N-2.1x5.5 (1 unit supplied with Pulsar) | 7E05029 |
| USB Interface (USB) legacy | Legacy smart sensor to USB interface (USB) with similar performance to Juno+ but larger size (155 x 90 x 34mm) including analog output. See pages 124 & 125 for more information. See full USBI product page in the Ophir website. | 7Z01200 |

2.2 PC Interfaces

2.2.1 PC Connectivity Options for Power/Energy Measurement



2.2.7 Summary of Computer Options for Ophir Meters and Interfaces

Communications

With Ophir RS232, USB, Bluetooth and GPIB communication options you can transfer data from the sensor to the PC in real time or offline. You can also control your Ophir power meter from the PC.

- USB on Nova II, Vega, StarBright, Centauri (optional on StarLite) power meters and Juno, Juno+, Pulsar and USBI PC interfaces
- Bluetooth wireless on Quasar interface
- RS232 on LaserStar, Nova II, Vega, StarBright and Centauri optional on Nova
- GPIB optional on LaserStar
- Ethernet on EA-1 interface

Ophir Power Meter and Interface Specifications

| Model | Centauri | StarBright | Nova II / Vega | StarLite | LaserStar | Nova | Juno / Juno+ | Pulsar-1, 2 or 4 | EA-1 | Quasar Bluetooth |
|---|--|---|---|---|--|---|---|--|---|---|
| Communication method | USB / RS232 | USB / RS232 | USB / RS232 | USB ^(d) | RS232 / GPIB | RS232 | USB | USB | Ethernet | Bluetooth |
| Power Measurement | | | | | | | | | | |
| Power log period | 1s to 1000hr. | 1s to 1000hr. | 12s to 600hr. | N.A. | 12s to 600hr. | 5s to 24hr. | 5s to 500hr. | 5s to 500hr. | 5s to 500hr. | 5s to 500hr. |
| Max points stored onboard | unlimited | unlimited | Nova II 5400 Vega 27000 | N.A. | 5400 | 300 | N.A. | N.A. | N.A. | N.A. |
| Max points direct on PC | unlimited | unlimited | unlimited | N.A. | unlimited | unlimited | unlimited | unlimited | unlimited | unlimited |
| Analog output | 1V, 2V, 5V, 10V F.S. | 1V, 2V, 5V, 10V F.S. | 1V, 2V, 5V, 10V F.S. | 1V F.S. | 1V F.S. | 1V F.S. | N.A / 1V, 2V, 5V, 10V F.S. | N.A | N.A | N.A |
| Energy Measurement | | | | | | | | | | |
| Max real time data logging to PC | 20,000Hz USB 30Hz RS232 | 5000Hz USB 30Hz RS232 | >2000Hz USB ^(a) >30Hz RS232 | 20Hz ^(c) | >30Hz RS232 >1500Hz GPIB ^(a) | >10Hz | 10,000Hz ^(a) | 25,000Hz ^(a) | >25,000Hz ^(a) | 500Hz |
| Max onboard data logging rate | 20,000Hz | 5000Hz | 4000Hz ^(a) | N.A. | >1500Hz ^(a) | >10Hz | N.A | N.A | N.A | N.A |
| Data transfer rate of a data file from instrument to PC | ~20,000 points/s | ~500 points/s | ~500 points/s | N.A | ~500 points/s | ~50 points/s | N.A | N.A | N.A | N.A |
| Max points stored USB/onboard | unlimited | unlimited | Nova II 59,400 Vega 250,000 | N.A | 59,400 | 1000 | N.A | N.A | N.A | N.A |
| Trigger input and output | Trigger input to synchronize measurement of pulses | N.A | N.A | N.A | N.A | N.A | N.A | BNC trigger input to enable measurement of missing pulses. Can also be configured to give trigger output | N.A | N.A |
| Timing - time stamp for each pulse | resolution 1µs | resolution 1µs | N.A | N.A | N.A | N.A | resolution 10µs | resolution 1µs | resolution 1µs | resolution 10ms |
| General | | | | | | | | | | |
| Automation interface | yes | yes | yes | yes ^(c) | no | no | yes | yes | yes | no |
| LabVIEW VIs | yes | yes | yes | yes ^(c) | yes | yes | yes | yes | no | no |
| Maximum baud rate | 115200 | 115200 | 38400 | N.A | 38400 | 19200 ^(b) | N.A. | N.A. | N.A. | N.A. |
| PC file format | Text files, spreadsheet compatible ASCII | | | | | | | | | |
| TTL Out | yes | N.A | N.A | N.A | N.A | N.A | N.A | N.A | N.A | N.A |
| Number of sensors supported | 2 / 1 sensors per unit. Can combine several units with software for display of up to 8 sensors on one PC | One sensor per unit. Can combine several units with software for display of up to 8 sensors on one PC | One sensor per unit. Can combine several units with software for display of up to 8 sensors on one PC | One sensor per unit. Can combine several units with software for display of up to 8 sensors on one PC | One sensor per unit for single channel mode. Two sensors per unit for dual channel mode. | One sensor per unit. | One sensor per unit. Can combine several units with software for display of up to 8 sensors on one PC | 4 / 2 / 1 sensors per unit. Can combine several units with software for display of up to 8 sensors on one PC | One sensor per unit. Can combine several units with software for display of up to 8 sensors on one PC | One sensor per unit. Can combine several units with software for display of up to 7 Quasars on one PC |
| Compatible sensors | Supports most Ophir pyroelectric, thermal and photodiode sensors | | | | | | | | | |
| Power supply | Powered from internal rechargeable battery power supply | Powered from internal rechargeable battery power supply | Powered from internal rechargeable battery power supply | Powered from internal rechargeable battery power supply | Powered from internal rechargeable battery power supply | Powered from internal rechargeable battery power supply | Powered from USB | 12V wall cube plugs into jack on rear | 12V wall cube plugs into jack or PoE | Powered from internal rechargeable battery power supply |
| Dimensions | 47 x 200 x 130mm | 212 x 114 x 40mm | 208 x 110 x 43mm / 210 x 109 x 36mm | 211 x 114 x 40mm | 194 x 228 x 57mm | 205 x 95 x 39mm | 77 x 55 x 23mm / 105 x 80 x 29mm | 103 x 190 x 33mm | 93 x 73 x 29mm | 94 x 96 x 36mm |

Notes:

- (a) The above refers to the rate for logging every single point in turbo mode. Above that rate, the instrument will sample points but not log every single point.
 (b) For pyroelectric sensors, maximum guaranteed baud rate is 9600.
 (c) StarLite must be USB enabled in order to work with StarLab. If your StarLite has not been USB enabled, please contact your Ophir distributor in order to obtain a USB Activation Code.

2.3 Software Solutions

2.3.1 StarLab

StarLab turns your PC into a laser power/energy multi-channel station

Extensive Graphic Display of Data

- Line Plot, Histogram, Bar chart, Simulated Analog Needle
- Multiple data sets on one graph or separate graphs on the same screen

Advanced Measurement Processing

- Power/Energy Density, Scale Factor, Normalize against a reference
- Multi-channel comparisons
- User defined mathematical equations: channels A/B, (A-B)/C etc.
- Position & size measurement with BeamTrack sensors


Data Logging for Future Review

- Can be displayed graphically or saved in text format
- Easily exported to an Excel spreadsheet


Fully supports Centauri, StarBright, StarLite, Vega, Nova-II, Pulsar, Juno, Juno+, Quasar, EA-1 and USB1 devices with all standard Ophir sensors

Flexible Display Options with StarLab


Choose which channels to display




Maximize one of the sources




Setup screen



Choose line graph



or histogram



or needle display

One of the above screens is maximized

Multiple Sensors displayed together

Click on one of the channels


The numerical values are from the channel chosen



Here multi line graph display has been chosen

Settings and functions may be opened to adjust then minimized as needed

Additional functions are available from the "Functions" tab



Here multi line histogram display has been chosen

Functions and Logging

Functions

Click on f(x) to open another trace combining measured values

Define function combining measured values

New trace is now added per defined function

Logging

Click on log button and logging of values starts

Files are stored here. They may be viewed graphically OR numerically

Click on log button and logging of values starts

Files are stored here. They may be viewed graphically OR numerically


```

:PC Software:StarLab version 3.00 Build 19
:Logged:25/05/2014 at 09:33:22
:Channel B:vega Thermopile 3A-P-V1 (s/n:999999) V2.31 (s/n:657028)
:Channel A:Juno Photodiode P0300 (s/n:694646) 3N1.24 (s/n:606180)
:Math M:(A-B)^2
:Channel B:Statistics
:Min:3.440mw
:Max:12.22mw
:Average:7.882mw
:Std.Dev.:3.078mw
:Overrange:0
:First Pulse Arrived : 25/05/2014 at 09:33:22.562000

```

| Timestamp | Channel B | F(B) | Channel A | Math M |
|-----------|------------|------------|------------|------------|
| 0.000 | 1.762e-002 | 6.620e-003 | | |
| 0.064 | 1.836e-002 | 7.390e-003 | | |
| 0.128 | 1.911e-002 | 8.110e-003 | | |
| 0.136 | | | 1.067e-002 | 6.554e-006 |
| 0.193 | 1.986e-002 | 8.860e-003 | 8.480e-003 | 1.444e-007 |
| 0.203 | | | 6.540e-003 | 9.181e-006 |
| 0.256 | 2.057e-002 | 9.570e-003 | 4.900e-003 | 2.841e-005 |
| 0.269 | 2.123e-002 | 1.023e-002 | 3.550e-003 | 5.285e-005 |
| 0.321 | 2.182e-002 | 1.082e-002 | | |
| 0.354 | | | 3.400e-004 | 1.339e-004 |
| 0.384 | 2.232e-002 | 1.132e-002 | 3.600e-004 | 1.259e-004 |
| 0.406 | 2.291e-002 | 1.191e-002 | 4.800e-004 | 1.141e-004 |
| 0.449 | 2.258e-002 | 1.158e-002 | 7.600e-004 | 9.761e-005 |
| 0.865 | 2.216e-002 | 1.116e-002 | 1.340e-003 | 7.569e-005 |
| 0.870 | | | 2.370e-003 | 4.914e-005 |
| 0.928 | 2.164e-002 | 1.064e-002 | | |
| 0.936 | 2.104e-002 | 1.004e-002 | | |
| 0.993 | 2.038e-002 | 9.380e-003 | | |
| 1.003 | | | | |
| 1.056 | 1.558e-002 | 4.580e-003 | | |
| 1.070 | | | | |
| 1.120 | | | | |
| 1.136 | | | | |
| 1.184 | | | | |
| 1.203 | | | | |
| 1.664 | | | | |

BeamTrack Power/Position/Size Screens



Power / Position / Size screen



Position stability screen