

2.1.8 Accessories

Power Supply/Charger

Negative Polarity Power Supply/Charger for Centauri, Vega, Nova II, LaserStar, Nova, EA-1, Pulsar and Quasar
 Positive Polarity Power Supply/Charger for StarBright and StarLite & Power Supply/Charger for Juno-RS
 Push-Pull 2 Pin Power Supply for IS1.5-VIS-FPD-800 & IS1.5-IRG-FPD-800



Analog Output Connectors & Cables

Replacement standard analog output plug for most Ophir meters.
 Replacement analog output plug for LaserStar and for Juno-RS.



StarLite USB Activation Code

Software Activation Code that enables the StarLite meter to communicate in USB with our StarLab software suite.



Centauri Dual Channel Activation Code

Software activation code to field upgrade a Single Channel Centauri to Dual Channel capabilities.



USB Cables for Meters & Interfaces

Cables for communicating with the PC in USB – for use with our StarLab application, COM Objects, LabVIEW and to upgrade Firmware files.



Ethernet Cable for EA-1

Ethernet cross cable for communicating with an Ethernet network or direct to a PC for initial setup of the device – can be used with our StarLab or OphirEthernetApp applications or with customer's own software.



RS232 Cables for Meters & Interfaces

Cables for communicating with the PC in RS232 – for use with our StarCom application or to use our RS232 command set.



RS232 Module for Nova

Plug in module allows transfer of power and energy data to PC and remote control of power meters from PC. Includes manual and StarCom application program (refer to page 199).



IEEE488 GPIB for LaserStar

Option available with LaserStar power meter allowing LaserStar to operate with GPIB protocol. The option comes with StarCom software and also LabVIEW VIs to build LabVIEW applications.



Carrying Cases

Carrying case for StarBright, StarLite, Vega, Nova II or Nova power meters and up to 3 sensors.



Ordering Information

Item	Description	Ophir P/N
N Polarity Power Supply/Charger	Power Supply/Charger AC/DC 12V 2A N-2.1x5.5	7E05029
P Polarity Power Supply/Charger	Power Supply/Charger AC/DC 12V 2A P-1.35x3.5	7E05047
Push-Pull 2 Pin Power Supply	Push-Pull 2 Pin Power Supply 12V 2A	7E05047A
Juno-RS Power Supply/Charger	Power Supply/Charger AC/DC 12V 2A 2.5x5.5x13.8 S	7E05093
Standard Analog Output Connector	2.5mm mono jack	7E02008
LaserStar Analog Output Connector	Analog Output plug for LaserStar	7Z11004
Juno-RS Analog Output Cable	Cable Coax BNC-M to SMA-M RG-174 2 meter	7E01541
StarLite USB Activation Code	Software Activation Code that enables the StarLite meter to communicate in USB with our StarLab software suite	7Z11049
Centauri Dual Channel Activation Code	Software activation code to field upgrade a Single Channel Centauri to Dual Channel capabilities	7Z11056
Centauri / StarBright / StarLite USB Cable	USB-A to MICRO-B cable	7E01279
Nova II / Vega USB Cable	USB to mini DIN cable	7E01205
Juno / Juno+ / EA-1 USB Cable	USB-A to MINI-B Cable	7E01217
Pulsar USB Cable	USB-A to B cable	7E01202
EA-1 Ethernet Cable	Ethernet Cross Cable	7E01192
Juno-RS RS232 Cable	D9 Male/Female 1.8-2 meter	7E11216
Centauri / StarBright RS232 Cable	D9 to 3.5mm plug cable	7E01213
Nova II / Vega RS232 Cable	D9 to mini DIN cable	7E01206
Nova RS232 Module	RS232 adapter with 2 / 5 / 8 meter cable (including software)	7Y78105 / 7Y71052 / 7Y71051 ^(a)
LaserStar RS232 Cable	RS232 D9 to D25 Cable	7E01121
LaserStar IEEE Option	IEEE GPIB adapter for LaserStar	7Y78300 ^(a)
Carrying Case for StarBright, StarLite, Vega, Nova II and Nova	Carrying case 38x30x11 cm. For Power Meter and up to three sensors	1J02079

Note: (a) 7Y78105 (was 78105), 7Y71051 (was 781051), 7Y71052 (was 781052), 7Y78300 (was 78300)