

1.1.2.8 IPM Industrial High Power Sensor

1.1.2.8.1 IPM-10KW – Industrial Sensor

Features

- ISO/IEC 17025:2017, NIST traceable calibration
- Measure up to 11kW
- Modular architecture
- Heavy duty design with industrial interface and connectors
- Interlock to protect from overpower or cooling water failure
- Real time visibility, traceability and logging for predictive maintenance

IPM-10KW



Model	IPM-10KW	
Use	Laser power measurement in industrial environment up to 11kW	
Control	RS232	
Absorber Type	Beam deflector + broadband absorber	
Spectral Range μm ^(a)	0.9-1.1, 10.6	
Aperture mm	\varnothing 45mm	
Power Mode		
Power Range	100W – 11kW	
Power Scales	11kW / 6kW / 600W	
Power Noise Level W	5	
Backscattered Power	With IPM-SHUTTER10 or 10K-W/15K-W Scatter Shield, ~1% ^(b) Without IPM-SHUTTER10 or 10K-W/15K-W Scatter Shield 3.5 ^(b)	
Maximum Average Power Density kW/cm ²	See note ^(c) and table ⁽¹⁾ below	
Response Time with Meter (0-95%) typ. s	2.7	
Response Time with Meter (0-99%) typ. s	10	
Calibration Uncertainty $\pm\%$	1.9	
Power Accuracy $\pm\%$	5 ^(a)	
Repeatability $\pm\%$	0.4	
Linearity with Power $\pm\%$ (0-100% range)	2	
Linearity with Power $\pm\%$ (0-90% range)	1.5	
Energy Mode		
Energy Range	60J – 10kJ	
Energy Scales	10kJ / 5kJ / 500J	
Energy Accuracy	Additional 2% error to power accuracy	
Minimum Energy J	60	
Maximum Energy Density J/cm ²	See table ⁽¹⁾ below	
Cooling	Water ^(d)	
Minimum Water Flow Rate	8 liter/min at full power ^(d)	
Water Connectors	Quick connector for 12mm OD nylon tubing (see page 100)	
Weight kg	5	
Connectors ^(e)	 Interlock, M8 male, 3-pin RS232, M12 female 5-pin Flow meter – M8 female, 6-pin Power/IPM-COM, M12 male, 5-pin	
Cables ^(e)	Part	P/N
	RS232 cable, M12 male 5-pin to D9 female, 1.8m (supplied with sensor)	7Z10532
	Power cable, M12 female 5-pin to flying leads, 1.5m (supplied with sensor)	7E01519
	Interlock cable, M8 female 3-pin to flying leads, 1.5m (not supplied)	7E01513
	Water Flow Meter cable, M8 male 6-pin to flying leads, 1.5m (not supplied)	7E01536
Related Products ^{(a) (b)}	Name	Description
	IPM-SHUTTER10	Combined protective shutter with built in scatter shield, IP62 rated
	IPM-SHUTTER10 Window replacement kit	Replacement anti reflective coated window
	10K-W / 15K-W Scatter Shield	Scatter Shield for mounting on front flange
	IPM-COM-Profinet	Profinet communications adapter with AIDA connectors
	IPM-COM-EtherNet/IP-M	EtherNet/IP communications adapter with circular connectors (M12 & 7/8)
Compliance	CE, UKCA, China RoHS	
Part number	7Z07106	

Note: (a) Calibrated at 1.07 μm and 10.6 μm . When working at 10.6 μm (CO₂), if using the SHUTTER10 unit, the window should be removed.

Note: (b) IPM-SHUTTER10: When installed, use the NIRS or CO₂S setting to compensate for slightly higher reading.

10K-W / 15K-W Scatter Shield: When installed, use the NIRS setting to compensate for slightly higher reading. When not installed, use the NIR setting.

Note: (c) For circular beam centered within 25% of beam diameter. IMPROPERLY CENTERED BEAM CAN CAUSE DAMAGE TO SENSOR. Maximum tilt angle \pm 5 degrees. For rectangular beam please consult Ophir representative.

Note: (d) Water temperature range 18-30°C. Water temperature rate of change <1°C/min. Pressure drop across sensor 0.1MPa. The recommended flow rate can be lowered proportionately at lower than full power but should not be below 3 liter/min. The response time will be optimal with the recommended flow rate. For solutions for prolonged usage with untreated water (tap water, non DI water), please, contact Ophir.

Note: (e) See IPM User Manual for details of connectors and cables

Table (1)	Beam diameter	Max power density	Max energy density – by pulse width			
			1ms PW	3ms PW	10ms PW	100ms PW
	<15mm	10kW/cm ²	30J/cm ²	60J/cm ²	150J/cm ²	1350 J/cm ²
	15 – 20mm	7kW/cm ²	20J/cm ²	40J/cm ²	100J/cm ²	900 J/cm ²
	20 – 40mm	5kW/cm ²	15J/cm ²	30J/cm ²	70J/cm ²	600 J/cm ²
	40 – 45mm	4kW/cm ²	12J/cm ²	25J/cm ²	60J/cm ²	500 J/cm ²

* For drawings please see page 93

IPM-10KW

