

Main Memory Volatility Statement

Models: SP90390 / SP90391

Product Description:

BeamWatch / BeamWatch Plus

Memory Description:

This Camera contains the following memory devices:

<i>Volatile Memory Description</i>			
<i>Type</i>	<i>User modifiable (Y/N)</i>	<i>Function or Use</i>	<i>Process to Clear / Update</i>
SRAM	N	Functionality options	
SDRAN	N	Image buffer	

<i>Non-Volatile Memory Description</i>			
<i>Type</i>	<i>User modifiable (Y/N)</i>	<i>Function or Use</i>	<i>Process to Clear / Update</i>
FLASH	N	F/W code, Image data, Camera setting and data	Ophir service centers

General:

BeamWatch constants are stored in product Flash. The constants are generated when the product is sent through its calibration process in the factory and are fundamental to the product operation.

Note: The BeamWatch features are available using BeamWatch software, all relevant information is in the software user guide for your reference.

Shai Luria

QA manager

